

AIRENCE ROUTING USB CHANNELS

The return signals of the USB codec of the Aircence are standard routed as followed:

- 1 - USB audio codec (the codec corresponding to the first channel of the Aircence) – Program Pre fader
- 2- USB audio codec (the codec corresponding to the first channel of the Aircence) – Program Post fader
- 3- USB audio codec (the codec corresponding to the first channel of the Aircence) – Sub
- 4- USB audio codec (the codec corresponding to the first channel of the Aircence) – Aux

In Windows 7 you can rename the USB codec like in the picture below to make the codec selection in Aircast easier.

As for your encoder you can choose either Prog pre or Prog Post.

For voice tracking you can select Sub as an input so you can do your voice tracking during on-air by routing the mic channel to the sub bus.

